

Compatibilidades: Color Copier 110; Color Copier 120; Color Copier 140; Color Copier 145; Color Copier 150; Color Copier 155; Color Copier 160; Color Copier 170; Color Copier 180; Color Copier 190; COLOR COPIER 210; Color Copier 210LX; Color Copier 260; Color Copier 270; Color Copier 280; Color Copier 290; Color Copier 310; DESIGNJET 700; DESIGNJET 750C; DESIGNJET 750C+; DESIGNJET 755CM; DESKJET 1000C; DeskJet 1100c; DeskJet 1120c; DeskJet 1125c; DeskJet 1180c; DeskJet 1220; DESKJET 1220C; DESKJET 1220PS; DeskJet 1280; DESKJET 1600C; DESKJET 1600CM; DeskJet 3810; Deskjet 3816; DeskJet 3820; DeskJet 3822; DeskJet 6120; Deskjet 6122; Deskjet 6127; DeskJet 6162; DESKJET 710C; DESKJET 712C; DeskJet 720c; Deskjet 722c; DeskJet 770c; DeskJet 810C; Deskjet 812C; Deskjet 814C; DeskJet 815c; DeskJet 816c; DeskJet 820cxi; Deskjet 825c; Deskjet 825CVR; DeskJet 830c; Deskjet 840c; DeskJet 841c; DeskJet 842c; Deskjet 843c; Deskjet 845c; Deskjet 845CVR; Deskjet 850c; DeskJet 855c; Deskjet 870cxi; DeskJet 880c; DeskJet 882C; DeskJet 890c; DeskJet 895cxi; DeskJet 916c; DeskJet 920c; Deskjet 920CVR; Deskjet 920CXI; DeskJet 924c; DESKJET 9300; DESKJET 930C; DESKJET 930CM; DeskJet 932c; DeskJet 935c; DeskJet 940c; Deskjet 940CVR; DeskJet 948c; DeskJet 950c; DeskJet 952c; DeskJet 955c; DeskJet 959c; DeskJet 960c; DeskJet 970cxi; DESKJET 980C; DeskJet 980cxi; DeskJet 990cm; DeskJet 990cxi; DeskJet 995; DESKJET 995C; Digital Copier 310; Fax 1220; Fax 1230; Fax 1230XI; Officejet 1510ASL; Officejet 500XI; OfficeJet 5105; OfficeJet 5110; OfficeJet 5110V; OfficeJet 5110XI; OfficeJet G55; OfficeJet G85; OfficeJet G95; OfficeJet K60; OfficeJet K80; OfficeJet Pro 1150c; OfficeJet Pro 1170c; OFFICEJET PRO 1170CXI; OfficeJet Pro 1175c; OfficeJet R40; OfficeJet R45; OfficeJet R60; OfficeJet R65; OfficeJet R80; OfficeJet T45; OfficeJet T65; OfficeJet V30; OfficeJet V40; OfficeJet V40xi; OfficeJet V45; PhotoSmart 1000; PhotoSmart 1100; PhotoSmart 1115; PhotoSmart 1215; PhotoSmart 1218; PhotoSmart 1315; PhotoSmart P1000 series; PhotoSmart P1000xi; PhotoSmart P1100 series; PhotoSmart P1100XI; PhotoSmart P1115; PhotoSmart P1215; PhotoSmart P1218; Psc 1230; Psc 500; Psc 500CXI; Psc 500XI; Psc 700 series; Psc 720; Psc 750; Psc 750CXI; Psc 750XI; Psc 760; Psc 900; Psc 920; Psc 950; Psc 950VR; Psc 952.