

Compatibilidades: DeskJet 6940; DeskJet 6943; DeskJet 6980; DeskJet 6983; DeskJet D4160; DeskJet D4163; OfficeJet 6304; OfficeJet 6307; OfficeJet 6308; OfficeJet 6310; OfficeJet 6313; OfficeJet 6315; OfficeJet 6318; OfficeJet H470; OfficeJet K7100; OfficeJet K7103; OfficeJet K7108; PhotoSmart 2570; PhotoSmart 2571; PhotoSmart 2573; PhotoSmart 2575; PhotoSmart 2577; PhotoSmart 2578; PhotoSmart 8030; PhotoSmart 8038; PhotoSmart 8049; PhotoSmart 8050; PhotoSmart 8053; PhotoSmart C4100 series; PhotoSmart C4110; PhotoSmart C4140; PhotoSmart C4150; PhotoSmart C4170; PhotoSmart C4173; PhotoSmart C4180; PhotoSmart C4183; PhotoSmart C4190; PhotoSmart C4193; PhotoSmart C4194; PhotoSmart D5060; PhotoSmart D5065; PhotoSmart D5069; Psc 4180.