

Compatibilidades: DeskJet 5420; DeskJet 5440; DeskJet D4160; DeskJet D4163; OfficeJet 6304; OfficeJet 6307; OfficeJet 6308; OfficeJet 6310; OfficeJet 6313; OfficeJet 6315; OfficeJet 6318; OfficeJet H470; PhotoSmart 2570; PhotoSmart 2571; PhotoSmart 2573; PhotoSmart 2575; PhotoSmart 2577; PhotoSmart 2578; PhotoSmart 7830; PhotoSmart 7838; PhotoSmart 7850; PhotoSmart C3100 series; PhotoSmart C3125; PhotoSmart C3135; PhotoSmart C3140; PhotoSmart C3150; PhotoSmart C3170; PhotoSmart C3175; PhotoSmart C3180; PhotoSmart C3190; PhotoSmart C3194; PhotoSmart C4100 series; PhotoSmart C4110; PhotoSmart C4140; PhotoSmart C4150; PhotoSmart C4170; PhotoSmart C4173; PhotoSmart C4180; PhotoSmart C4183; PhotoSmart C4190; PhotoSmart C4193; PhotoSmart C4194; Psc 1500; Psc 1510; Psc 1513; Psc 1545; Psc 3180; Psc 4180.