

Compatibilidades: Color Copier 180; Color Copier 190; Color Copier 280; Color Copier 290; Color Copier 310; DeskJet 1180c; DeskJet 1220; DESKJET 1220C; DESKJET 1220PS; DeskJet 1280 series; DeskJet 3810; Deskjet 3816; DeskJet 3820; DeskJet 3822; DeskJet 6120; Deskjet 6122; Deskjet 6127; DeskJet 6162; DeskJet 916c; DeskJet 920c; DeskJet 924c; DESKJET 9300; Deskjet 9300c; DESKJET 930C; DESKJET 930CM; DeskJet 932c; DeskJet 935c; DeskJet 940c; DeskJet 948c; DeskJet 950c; DeskJet 952c; DeskJet 955c; DeskJet 959c; DeskJet 960c; Deskjet 960cxi; Deskjet 970cse; DeskJet 970cxi; DESKJET 980C; DeskJet 980cxi; Deskjet 990c; DeskJet 990cm; DeskJet 990cxi; DeskJet 995; DESKJET 995C; Digital Copier 310; Fax 1220; Fax 1230; OfficeJet 5105; OfficeJet 5110; OfficeJet G55; OfficeJet G55cxi; OfficeJet G85; OfficeJet G85xi; OfficeJet G95; OfficeJet K60; OfficeJet K60xi; OfficeJet K80; OfficeJet V30; OfficeJet V40; OfficeJet V40xi; OfficeJet V45; PhotoSmart 1000; PhotoSmart 1100; PhotoSmart 1100xi; PhotoSmart 1115; PhotoSmart 1215; PhotoSmart 1215vm; PhotoSmart 1218; PhotoSmart 1218xi; PhotoSmart 1315; PhotoSmart P1000 series; PhotoSmart P1000xi; PhotoSmart P1100 series; PhotoSmart P1100XI; PhotoSmart P1115; PhotoSmart P1215; PhotoSmart P1218; PhotoSmart P1315; Psc 700 series; Psc 720; Psc 750; Psc 760; Psc 900; Psc 920; Psc 950; Psc 950VR; Psc 952.